



Spherical surface:




Thin Lens and spherical mirrors (symmetric medium):



Lensmakers' formula:

$$\frac{1}{s_o} + \frac{1}{s_i} = \frac{(n_l - n_m)}{n_m} \left(\frac{1}{R_1} - \frac{1}{R_2} \right)$$



Angular Resolution of the Eye: *the smallest angular separation of two points that can be resolved by the eye.*

Magnifying Power:

$$MP \equiv \frac{\alpha_{with_aid}}{\alpha_{unaided}} \quad (\alpha \text{ is the angle subtended at the eye})$$

Magnifying Glass:

$$MP_{s_i=\infty} = \frac{D}{f} \quad MP_{s_i=D} = \frac{D}{f} + 1 \quad (D=25 \text{ cm is the near point of the human eye})$$


Microscope:

$$MP_{s_i=\infty} = -\left(\frac{L}{f_{obj}}\right)\left(\frac{D}{f_e}\right) \quad MP_{s_i=D} = -\left(\frac{L}{f_{obj}}\right)\left(\frac{D}{f_e} + 1\right)$$

(L=16 cm is the tube length of the microscope)


Refractive Astronomical Telescope:

$$MP_{s_i=\infty} \equiv -\frac{f_o}{f_e}$$




Matrices of Simple Optical Components

Propagation in homogeneous medium of thickness d :



$$M = \begin{bmatrix} 1 & d \\ 0 & 1 \end{bmatrix}$$


Refraction at spherical boundary:



Convex $R > 0$; Concave $R < 0$


$$M = \begin{bmatrix} 1 & 0 \\ \frac{n_1 - n_2}{n_2 R} & \frac{n_1}{n_2} \end{bmatrix}$$

Reflection from a planar mirror:




$$M = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix}$$

Refraction at planar boundary normal to the optical axis:



$$M = \begin{bmatrix} 1 & 0 \\ 0 & \frac{n_1}{n_2} \end{bmatrix}$$


Transmission through a thin lens:



Convex $f > 0$; Concave $f < 0$

$$M = \begin{bmatrix} 1 & 0 \\ -\frac{1}{f} & 1 \end{bmatrix}$$

Reflection from a spherical



Concave $R > 0$; Convex $R < 0$

$$M = \begin{bmatrix} 1 & 0 \\ -\frac{2}{R} & 1 \end{bmatrix}$$